

Installation and usage instructions for chains, hangers, and icicle lights

Dear Customers,

Thank you for purchasing our decor. We look forward to further collaboration with you.

Before first use, carefully study the following warnings and respect them during operation.

- * Do not use the products in an unpacked state.
- * During any manipulation (installation, disassembly), the products must not be connected to the power supply.
- * Do not expose connection points to direct water contact.
- * Protect against mechanical damage and tampering by children.
- * Do not cover the products during operation due to potential overheating.
- * Do not place in direct contact with flammable materials.
- * Do not use in adverse weather conditions (e.g., storms).
- * If you expect to operate them on metallic supporting surfaces, make sure they are properly grounded.
- * Before each use, perform a visual inspection to check the integrity and solidity of the insulation and covers.
- * Operate under occasional supervision.
- * If you discover any defects, discontinue operation immediately.
- * Store in a dry and warm place considering the nature of the product.
- * Products require gentle handling.
- * For outdoor use, plug into an outlet specifically designed for outdoor use, marked with IP-X4.
- * Use UV-resistant zip ties suitable for installation.
- * Secure the product tightly; do not use sharp metal tools or sharp fastening materials during installation to prevent product damage.
- * Ensure that connection and internal cables are not subjected to any load; it's not allowed to hang anything on them.
- * Light chains can be interconnected up to a maximum of five pieces.
- * Icicle lights can be interconnected up to a maximum of three pieces.
- * Light hangers cannot be interconnected.

For disposal of the above-mentioned goods, use designated containers.